

# Disinfection Mats



## Remedor Aquatic Disinfection Mats

*A key element to any biosecurity program, disinfection mats can be used anywhere shoes or boots require disinfection before proceeding*

### *What it is:*

1. The Disinfection Mat is uniquely designed to disinfect your boots or shoes before proceeding into a controlled area.
2. The Disinfection Mat consists of a very tough textile material, inside which is a special absorbent material. The sides and bottom are sealed to prevent leakage and very little solid matter will penetrate the mat's surface so there is little chance of neutralization of the disinfectant.



3. There are two sizes of the Disinfection Mat available.

**The Remedor Disinfection Mat** is 33 x 33 inches (84 by 84 cm) and is 1.2 inches (3 cm) deep. It will hold approximately 2.65 gallons (12 liters) of disinfectant solution.

**The Mini Remedor Mat** is approximately 18 x 18 inches (45 by 45 cm) and is 1 inch (2.5 cm) deep. It will hold approximately 0.9 gallons (3.5 liters) of disinfectant solution.

### *How it works:*

When standing on the mat, hydraulic pressure is created causing the disinfectant to rise up around boots and shoes.

### *How to use:*

1. Place the mat just outside the controlled area, preferably where there is an overhanging roof, or just inside the building (especially during winter).



**SYNDEL ASIA Sdn. Bhd.** (Co. Reg. No: 75135-M)  
Unit 5-1-9 (1<sup>st</sup> Floor), Jalan 3/109 F, Danau Business Centre,  
Taman Danau Desa, 58100 Kuala Lumpur, MALAYSIA  
Tel: (0) 603-79805103; Fax: (0) 603-79809103  
E-mail : syndel@streamyx.com

# Disinfection Mats



2. The Remedor Disinfection Mat holds approximately 2.65 gallons or 12 litres of disinfectant. The Mini Remedor Mat holds approximately 0.9 gallons or 3.5 liters of disinfectant solution. Remedor Aquatic is the recommended disinfectant and is considered the best virucide, bactericide and fungicide for the job when used at a 1% to 2 % solution. Do not use iodine, chlorine or similar type disinfectants as these may damage the mat.
3. To clean the mat, hose off the top and hang upside down on a rail to drain. If hung by the comers rather than over a rail, it is important to grab the mat approximately 3" into the mat's material so that both the outer covering and the inner liner are held firmly. Otherwise, the interior material could fall down inside the mat cover.
4. Replacing the Remedor Aquatic disinfectant solution depends on how often the mat is used. Cleaning and refilling can be done every day if used by many people, or left down for several days, depending on use. Very little solid matter will penetrate the surface of the mat, thus there is little neutralization of the disinfectant solution.
5. Remedor Aquatic can be poured into the mat using a bucket or watering can. The mat is easily washed off, drained and filled as required.



## *Where to Use:*

In front of all offices, livestock buildings, hatcheries, vet hospitals, and greenhouses etc.

Please contact Syndel Asia Sdn. Bhd. for additional product information and pricing

Distributed By:



**SYNDEL ASIA Sdn. Bhd.** (Co. Reg. No: 75135-M)  
Unit 5-1-9 (1<sup>st</sup> Floor), Jalan 3/109 F, Danau Business Centre,  
Taman Danau Desa, 58100 Kuala Lumpur, MALAYSIA  
Tel: (0) 603-79805103; Fax: (0) 603-79809103  
E-mail : syndel@streamyx.com